

These are the instructions on how to operate the MS250 snap clock feature.

MS250V22: 25 – 40 Snap Clock

Plug in MS250 to the 3 pin female plug

Snap Clocks will display 25

Push Clock On – clocks will count down

Push Reset once to return to 25 or push Reset twice for 40 seconds

MS250V23: 40 – 25 Snap Clock

Plug in MS250 to the 3 pin female plug

Snap Clocks will display 40

Push Clock On – clocks will count down

Push Reset once to return to 40 or push Reset twice for 25 seconds