

## PROGRAMMABLE SEGMENT TIMER INSTRUCTIONS- BRIEF

- I. Turn power on AFTER controls are plugged in.  
LCD Display: SEG 1 U 5 min.
- II. To change automatic segment time, enter a number (1-99), then press “D” or “AUTO TIME” switch.
- III. To change to a segment, enter a number (1-99), then press “A” or the
- IV. “SEGMENT #” switch.
- V. To program individual segments, go to the segment number (step III), then enter the time by entering a number and pressing the “B” key or the “TIME” switch. Repeat as needed. Change the INTER-SEGMENT TIME by entering a number and pressing the “F” key.
- VI. The “E” key will change the counting mode from UP to DOWN to UP, etc...
- VII. The “C” key or “START/ STOP” switch turns the timer on and off (“\*” on the display= on); Timer must be off to make any changes.

NOTE: Turn power on AFTER the controls are plugged in. Changes cannot be made if asterisk (\*) is showing.