

Installation of Goal Lights

1. The Goal lights are to be mounted on top of the Shot Clocks.
2. Remove the Digit from the face of the shot clock.
3. Mark the center of the shot clock and drill hole for the power cable to drop into the cabinet.
4. Mark the two outside holes to secure lights to cabinet and drill holes.
5. Mount the Goal lights on top of the shot clock cabinet.
6. Connect the Goal light power cables to the cable that is provided to the Black to Black, White to White.
7. Now open up the Interpreter Module IF2 and hook-up the Black wire to **HRN1** and the White to **HCOM** on the barrier strip on the IF2 module.
8. Replace the Digit back on the face of the shot clock and test.